

# User manual

## Weighing Monitor MR





## INDEX

1.	Introduction .....	4
2.	Physical features .....	4
	2.1 Front panel and dimensions .....	4
	2.1.1 Buttons .....	5
	2.1.2 Indicators.....	5
	2.2 Connections.....	6
	2.2.1 Low side connections .....	6
3.	Menu navigation.....	7
4.	Main menu .....	8
	4.1 Access codes.....	9
	4.2 Display submenu .....	10
	4.3 Adjustment submenu.....	11
	4.4 Working mode selection.....	15
	4.5 Scale mode.....	16
	4.5.1 Configuration menus in this mode.....	16
	4.6 Peak value mode.....	19
	4.6.1 Configuration menus in this mode.....	19
	4.7 Pulse counter mode.....	21
	4.7.1 Configuration menu in this mode.....	21
5.	Electrical specifications .....	22
6.	Glossary .....	22
7.	Error codes .....	23

## 1. Introduction

The MR1 weighing monitor is a multifunction equipment designed for a variety of applications in the industrial weighing field. It can monitor signals from load cells as well as control the industrial weighing operations without the use of a PLC nor personal computer.

The equipment is provided with a special menu structure that it changes depending on the working mode selected. This feature avoids the showing of parameters of other modes not needed and so the system is easier to handle.


Three working modes are available:

- Weighing scale
- Peak value reading
- Pulse counter for fluids measurements

The unit can power up to 12 load cells of 350 Ohms.

## 2. Physical features

### 2.1 Front panel and dimensions



#### Box specifications

- V0 fireproof
- IP-50

MR1 is made in a standard enclosure DIN43700 IEC 61554 model 445-163.  
Dimensions: 138 x 96 x 48 mm.

### 2.1.1 Buttons

Three buttons provide access and navigation through the menu to program all necessary parameters of the unit.

The function of the fourth button is to start process.



Menu button / access to formulas.

Keep pressed to enter into the main menu or exit from menus

Press repeatedly to navigate through the submenus of the same level

Enter button / peak value functions



During menu navigation: Enter to modify a parameter.

While modifying a parameter: Chose digit to change



Increment button / tare function

During menu navigation: Shows the stored value of the selected parameter.

While modifying a parameter: Change the blinking digit incrementally or change the different options when the parameter is not numeric.

During decimal point modification: change its position.

Start

Start process button


In the mode *Pulse counter for fluids measurements*, this button starts, pauses and stops the process.

### 2.1.2 Indicators

- 6 digits display.
- LEDs from 1 to 5 show the state of relays/alarms.
- ►T◄ Tare. Lights when a tare is done.
- Tx: Blinks when a USB communication is active.

## 2.2 Connections

All connectors are in the rear panel.





### 2.2.1 Low side connections


- Load cells connections





Connector	Function	4 wires load cell	6 wires load cell
SHIELD	Shield connection	Shield	Shield
-IN	Negative signal	White	White
+IN	Positive signal	Green	Green
-EXC	Negative supply	Black	Black and Blue
+EXC	Positive supply	Red	Red and Yellow

- USB: Type B USB. Communications with a personal computer.
- EXT-GND: Input for the reading of a external dry contact in the counter mode.
- Power supply: Grounded 230Vac.

### 3. Menu navigation


- Keep  pressed to enter into main menu.
- Press  repeatedly to navigate through submenus and parameters of the same level.


The main menu is cyclic, at the end of the chain of all items, the symbol  appears and the cycle starts again from the beginning.


- Press  to enter into a submenu or parameter.
- Once inside a parameter, it will can be modified with  and .
- Press  twice to validate the data introduced.

If this button is not pressed the second time before display blink ends (ten seconds), the changes will not be stored.


This is the way for all submenu and parameters of the unit.


When the programming process has been done, press  more than 2 seconds to exit.


To check a parameter during navigation, keep pressed , the unit will show the current value of the parameter selected.

At the end of any menu or submenu will appear .

## 4. Main menu



Keep pressed  more than 2 seconds to enter/exit of the menu.

To enter in any submenu or parameter press .

\* It appears or not depending on the working mode selected.




## 4.1 Access codes

`LoadES` [0:999999]

This is a method to prevent the changing of parameters accidentally by enabling or not of critical functions of the unit.

- **Code 123456** (*Permit to modify weighing adjustment parameters*).

This code opens the access to modify the adjustment parameters of the load cell signal. Such parameters are shown starting with a dash `-ZERO-` `-LOAD-` `-SLOPE` `-CALF-`.

In case of enter into the menus without this code, the adjustment parameters can be checked pressing , but they can't be modified.

When the code is entered, display shows the message `Access` momentarily, as a acknowledge of open access.

To abort the access, return to `LoadES` menu and enter the code 123456 again or exit of all menus and wait 10 minutes. When the operation aborts the unit shows in display always the message `Access` momentarily.

- **Code 031025** (*Restoring the factory settings*)


With this code, the unit initializes and all parameters will be set by default.

When this code is entered, the unit shows `Reset` in display momentarily, as a acknowledge.

Some parameters are not affected by this operation, they are the following:

- Formulas used for dosage. `F 00`
- Adjustment parameters of load cell signal ( `-ZERO-` `-LOAD-` `-SLOPE` `-CALF-`).
- Working mode selected `MODE`.

## 4.2 Display submenu





- **dPounb** **Decimal point:**

This choice allows to see the value in tons, grams or kilograms with resolution needed.


- **rounb** **Rounding:**

The weight shown can be rounded to prefix values: 1, 2, 5, 10, 20, 50, 100 y 200.

Press  to access the parameter and press  to modify it.

### 4.3 Adjustment submenu

Here can be done the adjustment regarding with the load cells and the analog input.




**Notice:** The parameter `CODES` must be set with the access code before to modify the parameters starting with a dash

Process to adjust the load cells can be done in two ways:









Zero and sensitivity adjustment with a well know weight


Zero adjustment and adjust with the calibrated value of load cell

- **Zero adjustment**







 [-199999 ÷ 999999]


Usually, this adjustment is done without load, but also it can be done with a approximated known weight to avoid the emptying of tanks.

1. Select the option  in the menu.
2. Check there's no load in the scale and press . The unit will show in display the zero value (by default: 000000).
3. In case of do this operation with a approximated known weight, enter the value of the weight in the scale using  and  buttons.
4. Press  to save. All digits will start to blink.
5. While display is blinking, press  to confirm the operation. Then a 10 seconds countdown will start (it can be skipped pressing , in order to do the operation quicker). After this, the data is stored.
6. After, the display will show .

*Notice:* If  button is not pressed before the blinking ends, the operation is not validated.






- **Sensitivity adjustment with a well known weight (for all kinds of load cells).** -LOAD- [-199999 ÷ 999999]


1. Place over the scale a well known weight (it is recommended to place minimum a 50% of the full capacity).
2. Select the option -LOAD- of the menu and press  to access.
3. Enter the value of a well known weight using   buttons.
4. Press  to save. All digits will start to blink.
7. While display is blinking, press  to confirm the operation. Then a 10 seconds countdown will start (it can be skipped pressing , in order to do the operation quicker). After this, the data is stored.
5. After, the display will show -LOAD-.

*Notice:* If  button is not pressed before the blinking ends, the operation is not validated.

- **Sensitivity adjustment with the calibrated value of load cell** -SLOPE

This method is less accurate because the system tolerances are unknown.

1. Select the option -SLOPE of the menu and press  to modify the value.
2. Enter the value for slope of the load cells using  .:  
To get this value, do the next operation:  
SLOPE = nominal load ÷ sensitivity (See the following examples 1 y 2)
3. Press  to save. All digits will start to blink..
4. While display is blinking, press  to confirm the operation.
5. After, the display will show -SLOPE .

*Notice:* If  button is not pressed before the blinking ends, the operation is not validated.

## Weighing Monitor MR

### EXAMPLE 1:

One load cell:            Nominal load     = 1000 kg.  
                                 Sensitivity         = 2.000 mV/V.

SLOPE in the unit =  $1000 \text{ kg} / 2.000 \text{ mV/V} = 500$ .

### EXAMPLE 2:

Specifications of three load cells connected in parallel:

Load cell 1:            Nominal load     = 1000 kg.  
                                 Sensitivity         = 2.000 mV/V.

Load cell 2:            Nominal load     = 1000 kg.  
                                 Sensitivity         = 2.002 mV/V.

Load cell 3:            Nominal load     = 1000 kg.  
                                 Sensitivity         = 1.980 mV/V

Calculate the SLOPE of all of them individually and then sum the three values:

SLOPE 1 =  $1000 \text{ kg} / 2.002 \text{ mV/V} = 499.5$

SLOPE 2 =  $1000 \text{ kg} / 2.000 \text{ mV/V} = 500.0$

SLOPE 3 =  $1000 \text{ kg} / 1.980 \text{ mV/V} = 505.0$

SLOPE in the unit =  $499.5 + 500.0 + 505.0 = 1505$ .

NOTICE: The nominal load as well as sensitivity are parameters provided by the manufacturer of the load cells.

- **Filter adjustment of the load cell signal**

**FILTER** [0 ÷ 12]

Filters the input signal. The higher this value, the measure is more stable with a lower sample rate. It is recommended a value of 9.

- **ADC tolerance adjustment:**

**-CALF-** [0 ÷ 10000]

This value is set by the manufacturer and shown in the serial number label.

- **Display of the load cell signal**



**SCALE** [-3,9 ÷ 3,9]

Read only parameter in mV/V.

## 4.4 Working mode selection


**MODE** Three working modes are available:

- **SCALE** Weighing scale.
- **PV** Peak value reading.
- **Count** Pulse counter for fluids measurements.

Notice: Press  to access the parameter and press  to modify it

## 4.5 Scale mode

### 4.5.1 Configuration menus in this mode







- **Auto-zero submenu:**




Parameter to set the zero when there is not load over the scale but it still has some residue on it.


- **Auto-zero limit:**


 [0 ÷ 1000]

This is the range of weight. For example, if  is set to 10 kg. and the load over the scale is 100 kg., an auto-zero will be done when the load is between 90 and 110 kg.

If  is set to 0, this function is not enabled.

- **Auto-zero time:**

 [0 ÷ 100]





This is the minimum time between two auto-zero operations. If  is set to 0, the operation can't be done.

- **Tare activation:**

 [Yes ÷ No]

Activates/deactivates the tare function.

It is activated, in weighing mode:

- Press once  to take a tare value. The indicator  will light.
- Press  more than two seconds to eliminate the tare. The indicator  will turn off.

- **Alarms submenu:**

ALARM

The weighing scale mode provides five level alarms. Parameter **LEVEL** is independently configurable, the parameter **HYSERIS** is common to all of them.

- **Alarms 1 to 5:**

AL 1 - AL 5

- **Level:**

**LEVEL** [-199999 ÷ 999999]

This is the weight alarm level. If the weight applied is higher than this value, the corresponding alarm will activate and its relay associated will change its state. If there's no relays, only will activate the corresponding indicator.

- **Hysteresis:**


**HYSERIS** [0 ÷ 1000]

Sets the hysteresis value for all alarms.

Example: if the parameter **LEVEL** of some alarm is set to 100 kg. and HISTERESIS value set to 10 kg., the alarm will be activated when the load overcomes 110 kg. After, during unloading, this alarm will not be deactivated until the load is less than 90 kg.

## 4.6 Peak value mode


### 4.6.1 Configuration menus in this mode




- Configuration:**

**Conf** [Pv\_1 ÷ Pv\_2]

Pv\_1: The peak value is shown continuously.

Pv\_2: The display shows the current weight. The peak value can be checked using the  button.

In both cases the peak value can be deleted pressing twice the  button while such value is showing in display.

- Peak Start Level:**

**PSL** [0 ÷ 999999]

This is the start level of the peak value record.

The peak value record is restarted every time the load go above this level upwards.

If PLS set to 0 this function is disabled.

- **Peak alarm submenu:**

**ALP-P**

The unit provides two security alarms, **AL P1** and **AL P2**.


- **Level:**

**LEVEL** [-199999 ÷ 999999]

This is the level of the alarm. If the peak value is higher than this value, the corresponding alarm will be activated and the associated relay will change its state.

## 4.7 Pulse counter mode

### 4.7.1 Configuration menu in this mode



- **Automatic unloading**

Auto-U (No) Read-only parameter

Automatic unloading is not available in this version of the unit (there are no output relays to do it).

- **Pulses per display point:**


PP [0 ÷ 1000]

Number of pulses necessary for increment the value that is shown in display.

- **Inactivity time to set to 0 the display (in seconds)**

Zero-t [0-100]

This is the time with no pulses received by the unit to set the display to zero.

If Zero-t is set to 0, only is available the reset by pressing the  button.

- **Counting process**

This process counts pulses received in the external input (EXT and GND) of the rear panel of the unit.

## 5. Electrical specifications











Nominal tension: 230 Vac / 50- 60Hz.

Maximum current: 80 mA.







Shortcircuitable power supply. 100 mA fuse.

## 6. Glossary

ADJUST	ADJUSTMENTS
AL-ERR	PROCESS ERROR ALARMS
ALARM-L	LEVEL ALARM
AL L1	LEVEL ALARM 1
ALARM-P	PEAK VALUE ALARM
AL P1	PEAK ALARM 1
A_ZERO	AUTO ZERO
AUTO	AUTOMATIC
-CALF-	ADJUSTMENT OF THE ADC CALIBRATION
CODES	CODES
CONF	CONFIGURATION
COUNT	COUNTER
CPP	COUNTS PER POINT
DPPOINT	DECIMAL POINT
DISP	DISPLAY
FILTER	ADC FILTER
HYSTER	HYSTERESIS
LEVEL	WEIGHT LEVEL
LIMIT	LIMIT
-LOAD-	WEIGHT FOR THE LOAD ADJUSTMENT
MODE	WORKING MODE
OVER	EXTRA COUNT
OVERL	OVERLOAD
PSL	PEAK START LEVEL
PV	PEAK VALUE

	PEAK VALUE IN FIRST PLANE
	PEAK VALUE IN SECOND PLANE
	RESET
	ROUNDING
	SCALE
	LOAD CELL SIGNAL IN mV/V
	SLOPE OF THE LOAD CELL
	TARE
	TIME
	WEIGHT FOR THE ZERO ADJUSTMENT

## 7. Error codes

	<b>Error description</b>	<b>Action</b>
	Load cell is not properly connected, it or its cable is damage.	Check the load cell connection.
	Negative overflow. The load cell is giving a negative signal too high.	Check the load cell connection because it should be no negative charge.
	Positive overflow. Load cell is holding a higher load than its nominal value.	Change load cell by another with higher nominal load.
	Polarity error. This happens when the unit adjusts the weight with the wrong load cell polarity, or the weight is not in the cabin during the adjustment.	Check the load cell connections. Adjust the zero and weight again.
	Loss of data in memory.	Two possibilities: 1. Search the parameter lost and reprogram it. 2. Restoring the factory settings.
	Load cell with very low sensitivity. Usually the unit is wrong adjusted.	Adjust the zero and load again.

Weighing Monitor MR



*Dinacell Electrónica s.l.*

*Pol. Ind. Santa Ana.*

*C/ El torno, 8.*

*28522 Rivas Vaciamadrid*

*Madrid (SPAIN)*

*124-6128-02*

*28/05/2012*